

# APPLICATION NOTE

**Connecting two Phoenix  
Studio Audiocoders  
through a  
point-to-point IP radio link  
operating in the 5 GHz band**



## **AEQ PHOENIX AUDIOCODECS. APPLICATION NOTE 4**

### **Connecting two Phoenix Studio Audiocoders through a point-to-point IP radio link operating in the 5 GHz band**

#### **1. DESCRIPTION OF THE SCENARIO**

Recently several manufacturers have started to offer digital radio links with IP connectivity based on IEEE 802.11a, using extremely directive antennas that operate in a free RF band. These links can be used to transport data between several locations, to join venues of a same organization, or grant Internet access to places where ADSL is not available. The main features of these products are long range, low power consumption and nice cost effectiveness.

We are going to use them for bidirectional audio transport between two radio broadcast production centers in a same town, a radio studio and a transmitting center (STL, "Studio to transmitter link" application), or between a remote location where some event is being held and the radio studio.

We have evaluated two solutions with different cost and performance ranges.

Ubiquiti presents a wide range of systems with different performance levels and a very adjusted price that operate under the same setup/operation software platform, called AirOS v5, that is incorporated in the equipment as an embedded Web server. The IP Nanobridge M 5G22 system has been tested, but the procedure followed is very similar to tens of Ubiquiti products that are configured the same way.

On the other hand, we have also selected for our tests a system from Alvarion, BreezeNet B14. It is more costly, its configuration is less intuitive, but it is relatively capable without direct line-of-sight, a characteristic that can make it very useful in some cases where other equipments such as Ubiquiti's can't establish a link.

There are some other European and North-American manufacturers, each one with its own cost and functionality characteristics. But after the tests, we reached the conclusion that most of them will be able to work more or less easily with one or several pairs of Phoenix Audiocoders in order to send one or more bidirectional audio programs.


In fact, the large bandwidth offered by this kind of products allows sending one or more linear (uncompressed) audio channels through the same radio link (max. 2 stereo channels per Phoenix Studio).

## 2. REQUIRED HARDWARE

RS-1: Two AEQ Phoenix Studio professional audiocoders (or more pairs).

RS-2: Two Ubiquiti NanoBridge M 5G22, Alvarion BreezeNet B14 or similar antennas.

RS-3: Connecting cabling (4 Ethernet cables, 2 POE adapters).



Schematic of a radio STL setup based on AEQ Phoenix Studio

## 3. INSTALLATION

- ✓ Install one antenna at each of the ends of the communication to be established.



Front and rear images of the Ubiquiti and Alvarion systems

The installation of each antenna is usually made with the included mounting hardware.

- ✓ Connect the AEQ Phoenix Studio audiocodec to the NANOBridge M 5G22 antennas in each end. The antennas are fed by means of POE adapters, that combine data and power supply to the same RJ45 cable that is connected to the radio system.
- ✓ Connect the mains cable to the POE adapter that is supplied with each antenna.



Ubiquiti and Alvarion POE adapters

- ✓ Connect the Ethernet cable between AEQ Phoenix (use NET1 connector if possible) and the POE unit.

**IMPORTANT NOTE: use the “LAN” port for this connection, or permanent damage can be produced to the connected equipment.**

RECOMMENDATION: install a small Ethernet switch between the audiocodec and the POE unit that will allow you to connect other equipments such as a laptop that will help in the remote configuration of all the equipments connected in this setup. This will also allow you to connect several audiocodecs as hended for multichannel links).

- ✓ Connect an Ethernet cable from the POE adapter to the antenna back. Note that this port is labelled “POE” in the Ubiquiti unit and “Radio” in the Alvarion one.
- ✓ Connect the analog or digital audio inputs and outputs in the back of the AEQ Phoenix Studios. RECOMMENDATION: start with CH1 for this test.
- ✓ Connect the mains cords to each audiocodec.
- ✓ Turn all the units on.


#### 4. CONFIGURATION OF UBIQUITI NANOBIDGE M 5G22 ANTENNAS

In order to setup a link between two Ubiquiti NANOBIDGE M 5G22 or similar units, the Web server embedded in the antenna itself is used. We must have a computer connected to the each antenna, by means of a switch or a direct connection (in this case, we will substitute the PC by the audiocodec once the antenna is properly configured).


After having connected the PC to the Antenna, open a Web browser and type “<http://192.168.1.20>” in the URL bar (It may be necessary to configure the browser so it doesn’t use a proxy for local addresses).

Once we are able to connect to the Nanobridge, we will be presented a small Windows where it asks for an username & password. By default we must type “ubnt” in both fields. After this step is completed, we will enter the main screen, that shows a summary of the link status, present values for the basic configuration (depending on the operating mode), network parameters and traffic statistics of all the interfaces.

Network administration parameters, monitoring utilities as well as a useful antenna-alignment tool, ping, traceroute and speed tests are also accessible from the main screen.



- First of all, it is important that we change the IP addresses of at least one of the units, from the default value (192.168.1.20) to a different one, i.e. 192.168.1.21. In order to do that, just click on the Network tab:




The screenshot shows the 'NanoBridge M5' web interface with the 'NETWORK' tab selected. The 'Network Role' section has 'Network Mode' set to 'Bridge' and 'Disable Network' set to 'None'. The 'Network Settings' section has 'Bridge IP Address' set to 'Static' with an IP address of '192.168.1.20', a netmask of '255.255.255.0', and a gateway IP of '192.168.1.1'. Other settings include 'Spanning Tree Protocol' (unchecked), 'Auto IP Aliasing' (checked), and 'IP Aliases' (with a 'Configure...' button). The 'VLAN Network Settings' section has 'Enable VLAN' (unchecked). The 'Firewall Settings' section has 'Enable Firewall' (unchecked) with a 'Configure...' button. The 'Static Routes' section has a 'Configure...' button. A 'Change' button is located at the bottom right of the interface.

The new address (192.168.1.21) must be typed inside the “IP Address” field. Next click on “Change” button in order to apply the changes. Finally, we will be presented a window on the top part of the screen in order to confirm the new parameters. Just click on “Apply”.


From now on, once the antenna is restarted, we must change the IP address in the browser URL bar in order to continue connected to it.

- Next, it is necessary to establish the operating mode. In order to do that, click on the “Wireless” tab and in one of the antennas we will select the “Access Point WDS” mode, while in the other one we will select “Station WDS”. Remember to always apply the changes with the “Change” button.
- We also need to select the antenna physical type: please select “300 – 22 dBi” from the list that is shown besides the text “Antenna”.




From now on we should start getting received signal in both ends of the communications; this can be see in the main screen.


We can align the antennas using the information in this page (particularly with the "Signal Strength" information) in order to attain the strongest possible signal:



Please note that the, the better aligned the antennas are, the higher value of Signal Strength we will get. We can also use the Antenna Alignment utility in the tools menu:



The management window shows statistics of the transmitted and received IP traffic:



In order to monitor the received signal level, connecting to both antennas, aligning them and monitoring only one is enough, as the received level will be equivalent in the other end.

Nothing else is required to connect both antennas, although there are several optional parameters in order to establish security parameters, firewalls, etc.

Refer to the manual to get deeper information:

[https://dl.ubnt.com/guides/airOS/airOS\\_6\\_UG.pdf](https://dl.ubnt.com/guides/airOS/airOS_6_UG.pdf)

Or use the quick guide:

[https://dl.ubnt.com/guides/nanobridge/NanoBridge\\_M5\\_QSG.pdf](https://dl.ubnt.com/guides/nanobridge/NanoBridge_M5_QSG.pdf)

## 5. CONFIGURATION OF THE ALVARION ANTENNAS

In order to setup the link between two BreezeNet B14 (or other similar Alvarion antennas) the telnet interface embedded in the units is used. We must have a PC connected to it, by means of a switch or directly (in this case we will substitute the PC by the audiocodec once everything's properly configured).

- After having connected the cable to the computer, check that they are in the same network and that IP connectivity exists (use a Ping command for this purpose, for example). The default IP address of the antenna is 10.0.0.1, although once more it is convenient to change one of them so they can be distinguished once the link is established and they are part of the same local network.

**NOTE:** *this is the default IP address. Check that it hasn't been changed in any of the antennas before (because different addresses are required to operate the radio link, as stated above).*

- Once we can reach the antenna with a Ping command, we must open a telnet terminal to set it up properly: open a windows command window and type "telnet 10.0.0.1" (or the IP corresponding to the particular antenna). An user level will be asked for. We will type "3" (Administrator). Next, the password is required. The default one is "private". After that, we can start configuring the antenna.
- Check that the three green LEDs in the unit are ON (power supply, network and radio link).
- If not done before, it is important that we change the IP of at least one of the ends from the default address (10.0.0.1) to a different one, i.e: 10.0.0.2. In order to do that, just enter menu 3 (**Basic Configuration**), then menu 1 (**IP Address**) and type the new IP address.
- Although we are setting up a symmetrical point-to-point link, one of the antennas must be configured as Base Unit (BU) while the other one must be a Remote Bridge (RB). In order to check that, go to menu 2 (**Unit Control**) and test what's the available target mode in item D of the menu. If it allows you to change to RB mode, the unit is presently a BU, and vice-versa. If they are not different, go to menu 2 and make the required changes so you end up with 1 BU and 1 RB.
- From now on we should have signal at both ends. Check that the LED bar is illuminated with, at least, several green LEDs, indicating that the link has enough signal to noise ratio. You will observe that better S/N ratio is got by aligning the antennas properly. Just look for max. S/N.

Nothing else is required to connect both antennas, although there are several optional parameters in order to establish security parameters, firewalls, etc.

**IMPORTANT NOTE:** it has been observed that, once power is cycled to the antennas, they will not establish the link until we enter the telnet menu of one of them (BU, for example), even if no option is changed. So a PC is necessary to put the link to work.

Refer to the manual to get deeper information:

[http://www.intelek.cz/db/repository.nsf/v/E1B3DBF8B18B1D48C12576CD00442889/\\$file/Manual\\_Alvarion\\_breezenet\\_B\\_6.0\\_system\\_manual.pdf](http://www.intelek.cz/db/repository.nsf/v/E1B3DBF8B18B1D48C12576CD00442889/$file/Manual_Alvarion_breezenet_B_6.0_system_manual.pdf)

## 6. CONFIGURATION OF PHOENIX STUDIO FOR IP

When we connect the Phoenix to a network, we must have a free IP address within the range allowed in that local network. This network must be the same in the antenna.

- ✓ As an example, if the Ubiquiti antennas have IP addresses 192.168.1.20 (default one) and 192.168.1.21 (after we have changed it), we can assign the Phoenix Studio (and the used PCs) IP addresses 192.168.1.22 & 192.168.1.23, with a net mask 255.255.255.0, for example. The IP and mask of the Phoenix unit is configured under the menu “SYSTEM → SETTINGS → Ethernet Settings”, for each physical port. Only one port is needed, ETH1 for instance.
- ✓ With Alvarion units, if the antennas have the addresses 10.0.0.1 (default one) and 10.0.0.2 (after we have changed it), we can assign the Phoenix Studio (and involved PCs) IP addresses 10.0.0.3 & 10.0.0.4, with a net mask 255.255.0.0, for example. Again, the IP and mask of the Phoenix unit is configured under the menu “SYSTEM → SETTINGS → Ethernet Settings”, for each physical port. Only one port is needed, ETH1 for instance.
- ✓ Next, we must configure the selected audio channel to work in IP mode, “RTP direct point to point”. Choose the physical interface for the audio RTP stream to be the one with the cable connected to the antenna. In our example, we would choose ETH1. Make sure that the Alvarion equipment has port 1024 open. This is not required for the Ubiquiti units.
- ✓ After all this is done, select the audio coding mode. We recommend that the buffer mode is set as FIX, with a minimum size of around 40ms.
- ✓ The only part missing is to establish the communication. In order to do that, press the CALL button, type the IP of the other Phoenix unit in the “destination IP” field, and press CALL again, to start this side of the communication link.

This setup must be repeated in the other Phoenix, including the CALL (RTP protocol is connection-oriented, not call-oriented). Use the same audio coding scheme, of course.

You can establish a connection using SIP DIRECT mode in a similar way, by calling the units with the convention name “user@IP”. This procedure is further detailed in the Phoenix Studio User Manual.

Once both Phoenix show synchronization (green LED), the link is completed.



**APPLICATION NOTE:  
R+D DEPARTMENT, AEQ**

**MADRID (SPAIN)**

AEQ, S.A.  
Calle Margarita Sala 24  
Parque Científico Leganés Tecnológico  
28919, Leganés (Madrid)

[aeqsales@aeq.es](mailto:aeqsales@aeq.es)  
[www.aeq.eu](http://www.aeq.eu)